

5
4/6




HADLOW LINE SETUP MODES

Changing between 5-line & 4/6 line modes

ATTACHING THE DEPOWER BRIDLE


Attach Toggle G1 to the kite.

Pass the end of Toggle "G" through the pulley and then attach to the end of Toggle "G1" using a larks head knot (see page 4)



CHANGING BETWEEN 5 LINE AND 4/6 LINE MODES

N.B. The rear lines connect to the rear toggles in both 5-line mode and 4/6 line mode.



This diagram shows how you split the 5th Line "Y" bridle by removing Toggle "C"

Connect the 4m Bridle lines to join between the 18m and 4m flying lines.


Then connect the 4m Bridle lines using the toggles "T" to the end of the split 5th Line Bridle Lines



THE LARKS HEAD KNOT

How to connect the 4m Bridle lines to join between the 18m and 4m main flying lines


Step 1



Step 2



Step 3



PULLEYS & TOGGLES

How to connect the 4m Bridle lines to join between the 18m and 4m main flying lines

